



EXPLODED D/S ASSEMBLY

ASSEMBLED P/S ASSEMBLY

**Parts List**

ITEM	Part No.	QTY	DESCRIPTION
1	HT-RA004a	1	TENSIONING NUT / CENTRE PIN
2	HT-RA004b	1	TENSIONING BOLT
3	HT-RA001	1	WIRE CABLE PULLEY W/ BEARING
4	HT-RA004c	1	FLAT WASHER SPACER
5	HT-RA004d	1	STAR WASHER & FLAT WASHER
6	HT-RA004e	1	RETAINING SCREW
7	HT-RA002	1	D/S BRACKET
8	HT-RA003	1	P/S BRACKET